
Operation Guide 5373

CASIO®

. Your watch may differ somewhat from the one shown in the illustration.




Crown Operations

Some water-resistant models (100 meters, 200 meters) have a screw-in crown. When you need to perform a crown operation, rotate it towards you to unscrew it. Then pull the crown out. Avoid applying undue force when pulling. The watch loses its water resistance while the crown is unscrewed. After performing a crown operation, fully screw the crown back in.



If your watch has a rotary bezel...

You can rotate the bezel to align its ▼ mark with the minute hand. Then you will be able to tell how much time has elapsed since aligning the ▼ mark.



Specifications


Accuracy: ±20 seconds average per month Illumination: LED (light-emitting diode)


Battery: One silver oxide battery (Type: SR920SW) and one lithium battery (Type: CR1616)

Battery Life: Approximately 3 years on type SR920SW and type CR1616 (assuming one 9-second illumination operation per day)

• Always have both batteries replaced at the same time.

To adjust the time setting Note When the second hand is at 12 o'clock, pull the **Crown** out to Click 2. Take care that you set the correct AM or PM time.
When changing the time, move the minute hand four or five minutes past your final setting, and then back it up to the setting you want. Rotate the **Crown** to change the time setting. Push the Crown back in.





Illumination Precautions

- Illumination may be hard to see when viewed under direct sunlight.Frequent use of illumination runs down the battery.